

**BAREVNICE •
COLOUR CARD •**

z a p í n á m e c e l ý s v ě t




• NÝTOVACÍ KNOFLÍKY - BAREVNÝ LAK • PRESS BUTTONS - COLOUR LACQUER


AA 1950 WA 1951 WK 1956 WZ 1953 WP 1952 IZ 1987 JT 1989 YN 1955 YD 1954 ZZ 1959




QA 1960 QZ 1962 RE 1963 UZ 1957 GM 1912 QF 1961 UK 1964 UU 1965 VJ 1966 VX 1967



AP 1970 AK 1969 BJ 1973 BS 1903 BF 1930 VE 1958 EI 1979 DE 1975 DY 1977 ES 1978




CE 1938 CF 1974 CG 1939 DB 1910 OF 1994 OP 1995 OU 1996 OZ 1997 PJ 1998 EX 1999



FN 1902 KK 1900 FP 1904 GJ 1984 GR 1992 KR 1980 LY 1990 LK 1923 MI 1981 MR 1940



AU 1971 AX 1972 GP 1991 GO 1985 IP 1986 GB 1983 HD 1988 GL 1913 HK 1914 HN 1901



GX 1976 HX 1924



WM 1905 ZA 1916 NH 1982 ZK 1919 BX 1918 UM 1917 WB 1909 IO 1925

